

PRODUCT

ULTRAGRIP FURO ZERO**DESCRIPTION**

ULTRAGRIP FURO ZERO is an innovative product designed to quickly repair punctured sports balls, restoring their original functionality in minutes. Developed with a high-tech, water-based liquid formula, this sealant offers a practical and efficient solution for sealing punctures in balls from a wide range of sports, such as football, volleyball, basketball and handball. In addition to saving money by avoiding premature ball replacement, the product contributes to sustainability by reducing the waste of sports equipment. Application is simple and requires no advanced technical knowledge. Each bottle repairs 5 balls.

COMPOSITION

Formula: water, dispersed acrylic copolymer, curing agent and sealant. Technology: electrostatically charged nanoparticles that provide instant repair of punctures.

INDICATIONS

Sports balls with an inner tube or made of rubber. Available in a 50 ml package with syringe and applicator nozzle. Does not seal futsal balls.

PRODUCT IMAGES**BENEFITS**

- Proven efficiency: fast, long-lasting sealing that restores the ball to its original condition, even under extreme conditions.
- Versatility: compatible with a wide variety of sports balls.
- Savings: superior cost-benefit, avoiding the cost of replacing balls.
- Sustainability: reduces unnecessary disposal of balls, benefiting the environment.
- Ease of use: simple, intuitive application with no technical knowledge required.

PRODUCT

ULTRAGRIP FURO ZERO

HOW TO USE

1. Shake the bottle well before use.
2. Use the syringe to draw 10 ml.
3. Attach the applicator nozzle to the bottle or syringe.
4. Apply the product directly into the puncture or through the ball valve.
5. Use an air pump to inflate the ball immediately after application.
6. Position the ball with the puncture facing down and wait a few minutes for the sealing to complete.
7. Inflate the ball to the desired pressure and it is ready to use.

PRECAUTIONS

- Not suitable for futsal balls.
- Designed to repair punctures up to 2 mm in diameter.
- The ball must be inflated immediately after application for optimal distribution of the product inside.



TECHNICAL DATA PER UNIT

Packaging	Weight	EAN Code	Gross weight	Dimensions WxLxH mm
Bottle/syringe/ carton	50 g	0631430083785	93 g	45 x 45 x 170

PRODUCT

ULTRAGRIP FURO ZERO

SHIPPING BOX TECHNICAL DATA

Packaging	Weight	Units per box	Gross weight	Dimensions WxLxH mm
Corrugated box	3.72 kg	40	3.9 kg	200 x 500 x 175

Technical Manager: Paulo Ribeiro Jordão
 CRQ: 09404922 - IX Region
 INPI Registration: 925647780
 Product shelf life: 24 months from the date of manufacture

Company Name: Ultragrip Sports Indústria e Comércio Ltda.
 CNPJ (Brazilian Tax ID): 61.266.053/0001-43
 Rua Palotina, 433, Emiliano Perneta
 Pinhais, PR, Brazil
 ZIP Code (CEP): 83326-040

TAX INFORMATION

Tax Regime: Company under the Lucro Real (actual profit) regime
 NCM: 3506.91.20
 IPI: zero rate
 Origin: 0 - domestic
 PIS - 1.65% / COFINS - 7.6%
 ICMS - standard taxation
 ICMS-ST - not applicable to this product

Prepared by: Carlos Eduardo de Paulo
 Reviewed by: Paulo Ribeiro Jordão
 Approved by: Carlos Eduardo de Paulo
 Revision 1 - 10/05/2026

PRODUCT

ULTRAGRIP FURO ZERO

PACKAGING



Bottle Label



Syringe Label



Carton